


GUIDE: BUTTON MACHINE



- a. Metal Front (concave down)
- b. Paper (so you can read it)
- c. Plastic

- a. Metal Back (look at picture)